



PERFECT FOR YOUR SEWING PROJECTS

Challenge the Inner Fashionista in You

- Built-in Stitches, Buttonholes, and Fonts
 100 built-in sewing stitches, including 8 styles of one-step buttonholes, and 1 sewing lettering font.
- Back-Lit LCD Screen Display with Push-button Stitch Selection
 View the settings for selected stitches, stitch length and width, and the type of presser foot to use on the back-lit LCD display screen.
- Electronic Variable Speed Control
 Helps ensure you sew with safety and accuracy,
 particularly on intricate details or curves.
- Start/Stop Button and Foot Controller
 Sew with or without the electronic foot controller attached.
- Easy-to-Use Needle Threading System With the press of a lever, the thread is pushed through the eye of the needle.
- Built-in Free Arm
 Sew on cuffs and sleeves easily and accurately.

- Easy Bobbin Winding System
 With the fast and simple bobbin winder, you can wind bobbins for your convenience.
- Jam-Resistant Quick-Set Drop-in Top Bobbin
 Just drop in a full bobbin, pull the thread through the
 slot, and start sewing.
- Concealed Zipper Foot
 For your convenience when inserting an invisible zipper.
- Digital Stitch Length and Width Control
 Digitally adjust stitch length up to 5mm and stitch
 width up to 7mm.
- Reverse Stitch
 Enjoy greater stitch versatility.
- Included Dust Cover
 Help protect your machine from dust.
- Sewing Bundle Included Over \$100 Value
 Wide table, cording foot, and concealed zipper foot.

Basic Features

| LCD Display Size (Horizontal x Vertical) Inches | 2.0 x 0.7 |
|---|-------------|
| Display (Number of Colors) | Monochrome |
| Stitch Selection | Push Button |
| Screensaver | _ |
| Opening Screen | _ |
| On-Screen Help | _ |
| Built-in Languages | _ |
| On-Screen Editing | _ |
| Lighting | 1 LED |
| Thread Tension | Manual |
| Needle Threading System | Easy |
| Easy Bobbin Winding | • |
| Adjustable Bobbin Winding Speed | • |
| Thread Sensor | _ |
| Thread Sensor On/Off | _ |
| Automatic Thread Cutter | _ |
| Quick-Set Bobbin | • |
| Full USB | _ |
| Computer Connectivity with Update Capability | _ |
| Mouse Capability by USB | _ |
| Media Type | - |

Sewing Features

| Bed Area (Depth x Width) Inches | 5.2 x 8.6 |
|---|------------|
| | |
| Work space (Height x Width) Inches | 3.9 x 5.7 |
| Maximum Sewing Speed (Stitches Per Minute) | 850 |
| Knee Lifter | _ |
| Feed Dog | 6 |
| Back to Beginning Key | _ |
| Standard Presser Feet Included with Machine | 9 |
| Built-in Sewing Stitches | |
| (Includes Buttonhole Styles) | 100 |
| Buttonhole Styles | 8 One-step |
| Built-in Sewing Lettering Fonts | 1 |
| Stitch Width | 7mm |
| Stitch Length | 5mm |
| My Custom Stitch Feature | _ |
| Side Feeding | _ |
| Start/Stop Button | • |
| Speed Controller | • |
| Twin Needle Setting Key | _ |
| Needle Position Key (Up/Down) | • |
| | |

Quilting Features

| Automatic Height Adjuster AHA Feature | _ | |
|---------------------------------------|---|--|
| Presser Foot Pressure Adjustment | _ | |
| Presser Foot Leveling | _ | |
| Automatic Presser Foot Lifter | _ | |
| Pivot Function | _ | |
| Drop Feed/Free-Motion | • | |
| Free-Motion Quilting Foot | _ | |
| Built-in Quilting Stitches | • | |
| Included Quilting Feet | • | |
| Included Wide Table | • | |
| | | |

PACESETTER PS300T

SEWING

Included Accessories

- Buttonhole Foot (XC2691033)
- Overcasting Foot (XC3098031)
- Monogramming Foot (XD0810031)
- Zipper Foot (X59370021)
- Zigzag Foot (XC3021031)
- Blind Stitch Foot (SA133)
- Button Fitting Foot (XE2137001)
- Cording Foot (SA110)
- Concealed Zipper Foot (SA102)
- Wide Table (SAWT2)
- Dust Cover (XC8973021)
- Additional Accessories Included in Box

Recommended Optional Accessories*

- Open Toe Foot (SA147)
- Piping Foot (SA192)
- Additional Optional Accessories Available for Purchase

Machine Specifications

UPC: 012502658399 Weight: 10.6 lbs.

Footprint: 16.3" L x 7.0" W x 12.5" H

*Additional purchase required.

For more information, visit www.brothersews.com or call 1-800-4-A-BROTHER



